



FOB Handset Remote Programming



DIY Automatic Gate Kits
Solar & Low Voltage Specialists
PH 1800 111 930
info@gforceautogates.com.au
www.gforceautogates.com.au



#60-170

FOB Handset Remote



#60-171

2 Channel Receiver

Transmitter (Handset)- 433MHz Learning Receiver,

Coding using the Receiver

1. Check that all the Dip switches are 'OFF' on the Receiver.
2. Press and hold the program button No 1 on the Receiver.
3. Press the desired button on the handset remote for 2 seconds, receiver LED will flash RED then turn Green
4. Release the buttons on the Receiver and the Handset Remote.
5. Press Handset Remote button to test.

